
Multifrequency Receiver

The Multifrequency Receiver card receives multifrequency signals for the Feature Group D package.

MFR messages

MFR0001 I s c u MFR unit did not respond. The specified MFR unit has been disabled. Replace the indicated card.

MFR0002 I s c n Self-test of MFR card failed, where: n is the failure description.

1 = EPROM failed

2 = Processor failed

3 = Invalid result

The specified MFR card has been disabled.

Action: Replace the indicated card.

MFR0003 tn n1 n2 nn MFR unit failed MF tones test, where n1, n2, etc. is the list of input messages received by the MFR. In a successful test, 30 input messages are received, corresponding to KP, 0-9, ST, ST', ST'' and ST''''. Each tone input messages is followed by an interdigit silence input message. The specified card has been disabled.

Action: Replace the indicated card. Suspect faulty MFS if fault persists or if MFR units on more than one card are shown faulty.